

BATERIE TRX PRO ACER 7800MAH



Cena celkem:

1 199 Kč
(bez DPH: 991 Kč)

Běžná cena:

1 319 Kč

Ušetříte:

120 Kč

Kód zboží:

BATRX8140

Part No.:

TRX-AS10D31 XH

Záruka:

24 měs.

Stav:

Nové zboží

Popis

TRX AS10D31 XH

ZÁKLADNÍ SPECIFIKACE

Technologie baterie: Li-Ion

Napětí: 10,8 V, 11,1V

Kapacita: 7800 mAh

Baterie je záměnná s těmito produktovými čísly:

AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E, AS10D71, AS10D73, AS10D75, AS10D81

BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129, BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008, BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130

LC.BTP0A.015, LC.BTP00.123, 31NR19/65-2, 31CR19/652, 31CR19/65-2, 31CR19/66-2, AK.006BT.075, AK.006BT.080

Baterie je kompatibilní s těmito modely:

ACER

Aspire AS5253

Aspire E1

Aspire E1-421

Aspire E1-431

Aspire E1-471

Aspire E1-471G

Aspire E1-521
Aspire E1-531
Aspire E1-571
Aspire V3
Aspire V3-471
Aspire V3-471G
Aspire V3-551
Aspire V3-551G
Aspire V3-571
Aspire V3-571G
Aspire V3-731
Aspire V3-771
Aspire V3-771G
Aspire 4250
Aspire 4250G
Aspire 4250Z
Aspire 4251
Aspire 4251G
Aspire 4251Z
Aspire 4252
Aspire 4252G
Aspire 4252Z
Aspire 4253
Aspire 4253G
Aspire 4333
Aspire 4339
Aspire 4349
Aspire 4350
Aspire 4350G
Aspire 4352
Aspire 4551
Aspire 4551G
Aspire 4551P
Aspire 4552
Aspire 4552G
Aspire 4552-5078
Aspire 4560
Aspire 4560G
Aspire 4733Z
Aspire 4738
Aspire 4738G
Aspire 4738Z
Aspire 4738ZG
Aspire 4739
Aspire 4739Z
Aspire 4741
Aspire 4741G
Aspire 4741Z
Aspire 4741ZG
Aspire 4743
Aspire 4743G
Aspire 4743Z
Aspire 4743ZG
Aspire 4749
Aspire 4749Z
Aspire 4750
Aspire 4750G
Aspire 4750Z
Aspire 4750ZG
Aspire 4752
Aspire 4752G
Aspire 4752Z

Aspire 4752ZG
Aspire 4755
Aspire 4755G
Aspire 4755ZG
Aspire 4771
Aspire 4771G
Aspire 4771Z
Aspire 5250
Aspire 5251
Aspire 5252
Aspire 5253
Aspire 5253G
Aspire 5333
Aspire 5336
Aspire 5342
Aspire 5349
Aspire 5350
Aspire 5551
Aspire 5551G
Aspire 5552
Aspire 5552G
Aspire 5560G
Aspire 5733
Aspire 5733Z
Aspire 5736
Aspire 5736G
Aspire 5736Z
Aspire 5736ZG
Aspire 5741
Aspire 5741G
Aspire 5741Z
Aspire 5741ZG
Aspire 5742
Aspire 5742G
Aspire 5742Z
Aspire 5742ZG
Aspire 5749
Aspire 5749Z
Aspire 5750
Aspire 5750G
Aspire 5750TG
Aspire 5750Z
Aspire 5750ZG
Aspire 5755
Aspire 5755G
Aspire 5755Z
Aspire 5755ZG
Aspire 7251
Aspire 7551
Aspire 7551G
Aspire 7551Z
Aspire 7551ZG
Aspire 7552G
Aspire 7560
Aspire 7560G
Aspire 7741
Aspire 7741G
Aspire 7741Z
Aspire 7741ZG
Aspire 7750
Aspire 7750G
Aspire 7750Z

Aspire 7750ZG
TravelMate P243
TravelMate P243-M
TravelMate P243-MG
TravelMate P453
Travelmate P453-M
TravelMate P453-MG
TravelMate TM5740
TravelMate TM5742
TravelMate 4370
TravelMate 4740
TravelMate 4740G
TravelMate 4740Z
TravelMate 4740ZG
TravelMate 4750
TravelMate 4750G
TravelMate 4750Z
TravelMate 4750ZG
TravelMate 5335
TravelMate 5335G
TravelMate 5335Z
TravelMate 5340
TravelMate 5340G
Travelmate 5344
TravelMate 5360
TravelMate 5360G
TravelMate 5542
TravelMate 5542G
Travelmate 5735
TravelMate 5735G
TravelMate 5735Z
Travelmate 5735ZG
TravelMate 5740
TravelMate 5740G
Travelmate 5740Z
TravelMate 5740ZG
TravelMate 5742
TravelMate 5742G
TravelMate 5742Z
TravelMate 5742ZG
TravelMate 5744
TravelMate 5744G
TravelMate 5744Z
TravelMate 5760
Travelmate 5760G
TravelMate 6495
TravelMate 6495G
TravelMate 6495T
TravelMate 6495TG
TravelMate 6595
TravelMate 6595G
TravelMate 6595T
TravelMate 6595TG
TravelMate 7340
TravelMate 7740
TravelMate 7740G
TravelMate 7740Z
TravelMate 7740ZG
TravelMate 7750G
TravelMate 7750Z
Travelmate 7750ZG
TravelMate 8472

TravelMate 8472 HF
TravelMate 8472G
TravelMate 8472G HF
TravelMate 8472T
TravelMate 8472T HF
TravelMate 8472TG
TravelMate 8472TG HF
TravelMate 8473
TravelMate 8473G
TravelMate 8473T
TravelMate 8473TG
TravelMate 8572
TravelMate 8572G
TravelMate 8572T
TravelMate 8572T HF
TravelMate 8572TG
TravelMate 8573
TravelMate 8573G
TravelMate 8573T
TravelMate 8573TG

EMACHINES

D440, D442, D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730

GATEWAY

NS411, NS511, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53A, NV53A11u, NV55C, NV59C NV73A, NV79, NV79C

PACKARD BELL

EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44